


Curved Front Planter



The Curved Front Planter Kit contains:

- 5 Straight Composite Timbers each 44.5" long
- 1 Curved Composite Timber 44.5" long
- 10 Stacking Joints (5 two packs) each containing two long Stakes, four Brackets, two caps and screws.
- 4 Finishing Sleeves.

Introducing the 'Frame-It-All' Curved Front Garden

For general assembly you can find the instructions in the 2 Pack of Frame-it-all joints.

ECO-friendly

The framework utilizes our Composite Plastic Timbers. Manufactured from 40% wood fiber and 60% recycled polyethylene, the Eco-friendly durable composite wood grain plastic timbers never rot, warp or splinter. The cut to size timbers connect to brackets with our patented Stacking Joints stakes.

Dimensions:

Installation Notes:

Before starting to assemble the Curved Front Garden, refer to the parts diagram to understand how to screw the brackets onto the timbers. Remove the Stacking joints from the plastic bags and lay out the parts. Each of the joints comprises a stake and two brackets plus screws needed.

Tools Needed:

- Phillips head screwdriver
(electrical or battery operated preferred)
- Hammer

How the Joints Work







Diagram 2 Parts Identification



Stacking Joint



Special Installations:


Connect brackets parallel to all 8 curved timbers as shown in Parts Identification (P) above.

Assembly Instructions


1) Take two of the straight Timbers and carefully using a set square draw a straight line down the center of each to divide their length into two equal halves. Carefully saw each Timber into two halves with a hand saw or power saw.

2) With a screwdriver, (a power driver would be helpful) attach one bracket to each end of each of the Composite Timbers as shown in diagram (2) on the previous page.


3) Layout the base level of the Planter in a rectangular shape, with the curved timber facing front and insert one Stake through the brackets and into each of the four corners to lock all sides in place.




4) Add the second level of the Planter and insert one Stake through the brackets into the aperture on the top of the stake beneath it to lock the second level in place. Use two of the Finishing Sleeves instead of brackets for the upper level front corners as shown in diagram (3)



5) Add the remaining Timber to the rear wall of the Planter, using two of the Finishing Sleeves and locate the last two Stakes through the brackets into the aperture on the top of the stake beneath.



6) Add the Caps to each of the four top corner joints to finish off the Planter. You can also locate Solar Lights (#SL-1025, sold separately) as an added beauty feature.



Note:

If you plan to assemble the Kit for use indoors or on a hard surface, open two packs of the Stacking Joints, remove the four stakes and with a hacksaw, carefully cut the spike of each stake where indicated on the diagram. Use these four cut down stakes for the four corners of the base level of the planter.

Do not do this if you are locating the Planter outdoors on soil.